

Wallpaper Installation

Thank you for your order. We hope you love your new wallpaper.

Tag us @paperscapedesigns when install is complete. We would love to see your new space.

YOU CAN DO IT!	INSTALL	
<p>Installation is a breeze! Peel, Stick, and Create your beautiful new space.</p> <p>If you need further installation support, visit thepaperscape.com/install to watch our installation video.</p>	<p><u>STEP 1</u></p> <ul style="list-style-type: none">• Gather Supplies• Prepare Surface <p><u>STEP 2</u></p> <ul style="list-style-type: none">• Measure 23 inches from the left corner of the wall. Put a mark on the wall at the top, middle, and bottom.• Take the ruler, and draw a straight line ceiling to floor in line with the marks made on the wall. <p><u>STEP 3</u></p> <ul style="list-style-type: none">• Take panel #1, and peel backing 6 inches, and crease.• Place panel on wall starting at the top left corner of wall. Allow for 2-3 inches to go onto ceiling.• Align the right of the panel to the line drawn on the wall. There should be 1 inch of material on the adjacent wall. This will be trimmed after install is complete. <p><u>STEP 4</u></p> <ul style="list-style-type: none">• Begin to apply wallpaper to wall, and smooth by starting in the center and going down first. Then smooth it from the center of the panel out.• Peel the backing a foot at a time, and continue to smooth it until the bottom of the wall is reached and the full panel is applied.• Using the felt side of the smoothing tool, smooth the wallpaper again from the middle out to remove any bubbles and further adhere the wallpaper to the wall. <p><u>STEP 5</u></p> <ul style="list-style-type: none">• Repeat step 4 with each additional panel, aligning the left side of the new panel to the right side of the previous panel. There should be no overlaps or gaps. <p><u>STEP 6</u></p> <ul style="list-style-type: none">• Now that all panels are installed begin trimming. Trim the ceiling, side walls, and baseboard with a razor blade. Remove the excess wallpaper.	 <p>Install Video</p>
<p>BEFORE YOU START</p> <p>Materials Required</p> <ul style="list-style-type: none">• Razor Blade• Measuring Tape• Level• Pencil• Smoothing Tool• A Friend		
<p>Wall Preparation</p> <ul style="list-style-type: none">• First, use a warm, damp cloth to clean the wall surface, and allow it to completely dry. No chemicals or soap should be used when cleaning walls.• Remove outlet and light-switch covers.		
<p>PRO TIPS</p> <ul style="list-style-type: none">• Getting the first panel straight is the key to a successful installation. Spend the necessary time getting this one straight.• Always allow 30 days on a freshly painted wall before install.• If there are any bubbles or wrinkles, you can lightly press or smooth them out, or just peel back that area and re-apply.		